

ORIGINAL TOOLS

All items are listed for reference, but some items may not be available.

PART #	DESCRIPTION
Y-120 09220	TL-LR10 Lock Ring Tool for Disc Rotor SM-RT96/RT77 & HG Sprockets (Mounts to ratcheting socket wrench handle.)
Y-120 09230	TL-LR15 Lock Ring Tool for Disc Rotor SM-RT96/RT77 & HG Sprockets
Y-25U 15000	TL-LR20 Lock Ring Tool for Saint Disc Rotor SM-RT80/805
Y-1Z7 02000	TL-HG09 Lock Ring Tool for Capreo CS-HG70-S
Y-130 98000	TL-FC36 Crank Adaptor Installation Tool (For Hollowtech Crank)
Y-130 09210	TL-FC32 Crank Adapter Installation Tool for FC-M960/FC-M760/FC-M800/FC-7800
Y-130 09230	TL-FC33 Crank Adapter Installation Tool for Impact Wrench for FC-M800/FC-M760
Y-130 09220	TL-FC16 Crank Installation Tool for FC-M960/FC-M760/FC-M800/FC-7800
Y-130 09010	TL-FC10 Cotterless Crank Extractor
Y-130 09180	TL-FC15 Special Plug Tool for FC-5502/5505/M572
Y-130 09130	TL-FC20 Peg Spanner
Y-130 98230	TL-FC23 Hex Wrench T30
Y-130 98100	TL-FC31 Head Parts Spanner Set
Y-460 98630	TL-PD63 Cone Adjusting Tool Set for SPD Pedal
Y-400 01100	TL-PD77 Cone Adjusting Tool Set for PD-7700
Y-130 98250	TL-BB12 Press fit BB Installation Tool
Y-130 09075	TL-UN66 Bottom Bracket Installation Tool (Mounts to ratcheting socket wrench handle.)
Y-130 09073	TL-UN74-S Bottom Bracket Installation Tool
Y-708 00100	TL-8S10 Right-Hand Cone Removal Tool for Inter-8 Geared Hubs
Y-708 00200	TL-8S20 Right-Hand Cone Installation Tool for Inter-8 Geared Hubs
Y-708 00300	TL-8S30 Carrier Unit Gear Alignment Tool for Inter-8 Geared Hubs
Y-130 03100	TL-ST02 Return Spring Installation Tool (Round Spring)
Y-130 03200	TL-ST03 Return Spring Installation Tool (Square Spring)
Y-4A0 08000	Consumer Spoke Wrench
Y-4A0 14000	Shop Spoke Wrench
Y-42A 09000	TL-PD40 Pedal Lock Bolt Removal Tool
Y-130 09400	Adjust Nut Tool for FC-M970
Y-130 98200	TL-FC35 Crank Arm Installation Tool
Y-130 98000	TL-FC36 Crank Adaptor Installation Tool (For Hollowtech Crank)
Y-121 89000	TL-SR21 Sprocket (1/2" x 3/32") Removal Tool
Y-121 89010	TL-SR22 Sprocket (1/2" x 1/8") Removal Tool




PART #	DESCRIPTION
Y-130 09068	TL-UN75 Chainwheel Installation Tool FC-M750, M739, M570, M569, MC40 chainwheel installation tool for use with TL-UN96
Y-098 00010	TL-CT10 Cable Cutter (Use to cut outer casings, cables and pinch end caps.)
Y-098 9800	TL-CT11 Cable Cutter
Y-120 09050	TL-FW30 Multiple Freewheel Removal Tool
Y-25U 14000	TL-HA20 Ball Bearing Unit Installation Tool for Saint
Y-120 09040	TL-FW40 Single Freewheel Removal Tool. 2 Keys.
Y-120 09150	TL-FW45 Single Freewheel Removal Tool 4 Keys for BMX
Y-20W 00110	TL-FH81 R/H Adapter Open & Close Tool for FH-C810/C811
Y-130 98140	TL-CN23 Chain Connecting Tools for IG/HG/UG Chain (Spare Arrow)
Y-130 98150	TL-CN32 Chain Connecting Tools for IG/HG/UG Chains. 2 spare pins included in grip.
Y-230 90010	TL-HS10 Hub Cone Wrenches. 13/14mm, 2 wrenches
Y-320 90010	TL-HS20 Hub Cone Wrenches. 15/17mm
Y-25U 17000	TL-HB80 for HB-M800/M800A Spoke Lacing
Y-320 99010	TL-3R10 Hub Cone Wrenches. 14mm. 2 wrenches
Y-708 98010	TL-CJ10 Geared Hub Cable Setting Tool
Y-708 98020	TL-CJ40 Geared Hub Cable Setting Tool
Y-130 98170	TL-CN23 Chain Cutter Replacement Arrow
Y-130 98160	TL-CN32 Spare Pins (10 pcs./box)
Y-8H4 98030	Shimano Disc Brake Bleed Kit
Y-130 98170	TL-CN23 Spare Arrow (Option)
Y-130 98180	TL-CN27 Chain Cutter for IG/HG/UG Chain
Y-130 98190	TL-CN27 Spare Arrow (Option)
Y-121 5200	TL-CN41 Chain Wear Indicator
Y-3C2 28000	TL-HS21 Hub Spanner 23mm x 15mm
Y-3C2 27000	TL-HS22 Hub Spanner 24mm x 17mm
Y-20W 04000	TL-HS23 Hub Spanner 28mm x 18mm



TL-UN75



TL-CT10




TL-HA20




TL-CT11




TL-FW30



TL-FW40



TL-FW45



TL-FW81



TL-CN23



TL-CN32



TL-HS10




TL-HS20




TL-HB80




TL-3R10




TL-CJ10




TL-CJ40




TL-CN23



TL-CN27



TL-CN27



TL-CN41



TL-HS21
TL-HS22
TL-HS23



DISC BLEED KIT